



Cable # *DCF*

*FLOWMETER CABLE*



Connects the flowmeter to the Frequency interface.